

Dial Torque Wrench



APPLICATION

Dial torque wrench is the meter indicator which used in the torque testing of screw thread and fasteners in the measure range. Apply to the fasteners with high accuracy and requirement

- 1) Adjust to Zero firstly before using it.
- 2) Please rotate the button on the dial plate anticlockwise for right rotating usage, let the red driven index close to the black initiative index. Then turn the watchcase to make the driven index to the Zero.
- 3) Please rotate the button on the dial plate clockwise for left rotating usage, let the red driven index close to the black initiative index. Then turn the watchcase to make the driven index to the Zero.
- 4) To make the driven index to the value you need by forcing the fastener gently and reposefully.
- 5) The initiative index will be recovered to zero automatically, the driven index will be rested on the scale and you can read the accurate torque value if the force released. To rotate the button on the dial plate, make the driven index to zero for next usage.

LAS IMAGENES PUEDEN VARIAR DEL ORIGINAL; INFORMACIÓN SUJETA A CAMBIO SIN PREVIO AVISO

Cualquier duda o aclaración favor de llamarnos, estamos para SERVIRLE

México: [-52] 55-5300-4517, 55-53004271, 55-5312-2536

Querétaro: [-52] 442-340-0250, 442-340-0251, 442-193-5678

Puebla: [-52] 222-219-9999, 222-887-0114, 222-228-1633

www.cmsmetrology.com.mx

www.controly medicion.com.mx

Dial Torque Wrench

WARNING

- 1) Don't knock and dismantle it at random to affect the reading precision.
- 2) You can use it with two directions .but you cannot make it to loose the fasteners for reading precision purpose.
- 3) Don't exceed the torque value range.
- 4) Don't be close to the high temperature because of the plastic material used on the outer ring of dial.

TECHNICAL PARAMETER

Torque range (N.m)	Driving square (mm)	Measurement (LxWxH)	Weight (kg)	Precision (%)	Division value (N.m.)
0-1	6.3x6.3	310x72x57	0.8	±3%	0.01
0-3	6.3x6.3	310x72x57	0.8	±3%	0.03
0-6	6.3x6.3	310x72x57	0.8	±3%	0.06
2-10	6.3x6.3	310x72x57	0.8	±3%	0.1
4-20	6.3x6.3	310x72x57	0.8	±3%	0.2
6-30	12.5x12.5	310x72x70	0.8	±3%	0.3
10-50	12.5x12.5	310x72x70	0.8	±3%	0.5
20-100	12.5x12.5	310x72x70	0.8	±3%	1
40-200	12.5x12.5	600x72x75	1.5	±3%	2
60-300	20.0x20.0	800x72x82	2.0	±3%	3
100-500	20.0x20.0	800x72x82	2.5	±3%	5
200-1000	20.0x20.0	840x72x115	3.0	±3%	10
400-2000	25.0x25.0	905x80x115	3.5	±3%	20
1600-4000	25.0x25.0	905x80x115	5.0	±3%	40
3200-8000	38.0x38.0	905x160x160	42.0	±3%	80
4000-10000	48.0x48.0	905x200x200	45.0	±3%	100

LAS IMAGENES PUEDEN VARIAR DEL ORIGINAL; INFORMACIÓN SUJETA A CAMBIO SIN PREVIO AVISO

Cualquier duda o aclaración favor de llamarnos, estamos para SERVIRLE

México: [-52] 55-5300-4517, 55-53004271, 55-5312-2536

Querétaro: [-52] 442-340-0250, 442-340-0251, 442-193-5678

Puebla: [-52] 222-219-9999, 222-887-0114, 222-228-1633